N	ew	Pi	ro	d	п	cts	

- Gasket and seal kit with lock tabs and rocker cable kit. It includes all the gaskets and seals used on an M14P engine as well as some lock tabs and rocker cables (listing follows) \$550.00 per kit.
 - New production Magneto coils P/N MA-11600 \$455.00 each
- New Production Magneto Points kits BSM-11 Fixed point half and BSM-683 Movable point half \$337.70

_

M-14P gaskets and seals kit

	Description and the			
	location on the			
No.	Parts Catalog	Part number		
1	Gasket under the propeller governor R2-04 Page 8 fig. A1-1 item 35	14-10-21		
2	Gasket between the air compressor and the accessories case Page 5 fig. A0-1 item 12	14-11-546		
3	Gasket between the fuel pump 702ML and the oil pump MN14A Page 5 fig. A0-1 item 7	10-11-31		
4	0.1.	14 211 10		

17		77:	
7	Gasket	14-411-10	
	under the		
	generator		
	GSR3000M		
	Page 5 fig. A0-1		
	item 13		
8	Gasket	14-11-547	
	under the adapter		
	flange of the		
	generator		
	Page 48 fig. A7-4		
	item 3		
9	Gasket	15-11-120	
	between the		
	adapter of the		
tachometer and the			
	accessories case		
	Page 44 fig. A7-2		
	item 17		
10	Gasket	10-11-50	
	under the air start		
	distributor		
	Page 64 fig. C1-2		
	item 3		
11	Gasket	14-010-221	_
	between the front	1475 - 188 - 1880-1892-1892-1893-1893-1893-1893-1893-1893-1893-1893	
	cover and the		
	reducer case		
	Page 8 fig. A1-1		
	item 21	3/6	
		570	
10	O 1	14 010 250	

70		70-
15	O-ring under the rocker covers Page 17 fig. A3-1 item 27	14-04-513
16	O-ring on the bottom of the cylinders Page 17 fig. A3-1 item 41	14-704-04
17	Gasket between the reducer case and distribution cover and crankcase Page 8 fig. A1-1 item 11	14-01-527
18	Gasket between the rear cover and the accessories case Page 41 fig. A7-1 item 4	10-11-65
19	Gasket on the tap of the oil sump Page 35 fig. A5-1 item 33	14-602-104
20	Gasket between the	14-602-106

23	Gasket on the engine oil inlet Page 41 fig. A7-1 item 7	14-11-522		
24	Gasket on the breather of the reducer Page 8 fig. A1-1 item 37	14-10-541		
25	Gasket on the breather of the accessories case Page 30 fig. A4-1 item 10	14-217-21		
26	Gasket on the axle of the rockers Page 20 fig. A3-2 item 3	14-07-511		
27	Gasket on the air start valves Page 61 Fig. C1-1 item 2	14-27-531		
28	Safety at the bottom of the cylinders Page 17 fig. A3-1 item 9	14-204-16		